



FLINT STREET • FARTOWN • HUDDERSFIELD • WEST YORKS. • HD1 6LG

TEL: +44 1484 512354 • E-mail: info@beaversports.co.uk

SPELLBOUND LED MULTI-LIGHT

The Beaver Spellbound LED Multi-Light is an integral part of your life support system and should be treated with as much care as the rest of your accessories. Beaver Spellbound LED Multi-Lights feature a dual brightness LED Torch and high intensity flashing strobe, designed to maintain and attract visual contact during dark or poor visibility conditions. It has been manufactured to stringent quality control regulations, giving you a product which is strong, durable and will give years of trouble-free service, providing it is handled and maintained correctly.

DATE OF PURCHASE: _____

PURCHASED FROM: _____



SPECIFICATION

ALL BEAVER TORCHES AND STROBES ARE RoHS COMPLIANT & CE MARKED.

INTENSITY: **STROBE:** App. 250 Candela - cd/M2 **TORCH:** 150 Lumens

VISIBILITY: **STROBE:** Up to 2 Kilometres - 1.25 Miles **TORCH:** Up to 50 Metres

FLASH RATE: Between 5 and 6 flashes per Second

BATTERY: 3 AAA 1.5 Volt Alkaline Battery or Rechargeable Cells OR 1 18650 Lithium Battery

BURN TIME: **STROBE:** Minimum 4 Hours **TORCH:** 4 to 8 Hours

DEPTH: Waterproof to 50 Metres

CARE AND MAINTENANCE

1. Always ensure that the equipment you purchase is correct for the application for which it is intended, if you are not sure seek the advice of an authorised Beaver Dealer.
2. Install three new or freshly charged 'AAA' sized batteries by carefully unscrewing the Battery Compartment Cap from the main body of the unit and removing the battery holder. Insert the batteries into the holder, ensuring correct polarity. Place the battery holder back in to the main unit, ensuring that it is aligned correctly. Check the O-rings are in good condition and lubricated with silicone grease and fully screw the Strobe section back onto the body ensuring the threads are correctly aligned. If using a single 18650 Lithium Battery, remove the battery holder, place the battery inside the sleeve and follow instructions as stated.
3. Before use, ensure that the Beaver Spellbound LED Multi-Light is in good condition and free from any faults, ensure that the batteries have not expired and the battery compartment cap and LED Unit are securely tightened. Prior to each use, always check the torch and strobe functions are all working correctly by turning on for one minute.
4. The Beaver Spellbound LED Multi-Light may be carried hand held and secured to your wrist or other suitable point using the lanyard with adjustable cord lock supplied. Alternatively, it may be attached to a suitable position on your BCD or Harness using the side release clip supplied. This can be easily exchanged for the lanyard when required by unthreading the lanyard and replacing it with the stainless steel split ring connected to the nylon side release clip. Always ensure that The Beaver Electra LED Strobe & Torch is easily accessible and does not interfere with the safe operation of any other equipment, or will possibly catch or snag any items.
5. To turn the Torch on, carefully flick the switch near the torch end of the unit clockwise. To Dim the Torch, carefully flick the switch again. To operate in SOS - Flashing Strobe mode, flick the switch again.
6. To turn the unit off, flick the switch one more time, you can easily change between modes by flicking the switch until the desired function is reached.
7. To change the battery, please refer to Section 2 above.
8. After diving, rinse in fresh water and dry thoroughly.
9. Regularly apply silicone grease such as Beaver Aquagel to the O-Rings, this will prolong life and assist with battery changing.
10. Do not allow your Spellbound LED Multi-Light to be dragged on the floor, avoid contact with sharp objects and ensure that heavy items are not placed on top of the unit.
11. Store in a dry location with battery cells removed, away from direct sunlight and any heat sources. Avoid any contact with solvents, detergents, oils etc.
12. Spare parts are available from all Beaver Dealers, or directly from Beaver Sports.

CAUTION

All watersports are potentially hazardous. Before using any watersports equipment you should be properly trained and certified in its use by a recognised club or organisation.

PLEASE RETAIN WITH RECEIPT FOR GUARANTEE PURPOSES

www.beaversports.co.uk

e-mail - info@beaversports.co.uk