



WWW.BEAVERSPORTS.CO.UK

FLINT STREET • FARTOWN • HUDDERSFIELD
WEST YORKSHIRE • HD1 6LG • UK
TEL: 00 44 (0) 1484 512354

SCUBA RATTLE AND POINTER

Your Beaver Scuba Rattle and Pointer is an integral part of your diving accessories and should be treated with as much care as the rest of your equipment. It is intended for use during diving to point out features, wildlife and or situations to other divers while under water. This Beaver Scuba Rattle and Pointer has been manufactured to stringent quality control regulations, giving you a product which is strong, durable and will give years of trouble-free service, providing a few simple instructions are adhered to.

DATE OF PURCHASE: _____

PURCHASED FROM: _____

INSTRUCTIONS

1. Ensure the equipment you purchase is suitable for the application intended, if you are not sure, seek the advice of an authorised Beaver dealer.
2. Prior to use, ensure your Beaver Scuba Rattle & Pointer is in good condition and free from faults or damage that may impair it's proper use.
3. When diving, store your Beaver Scuba Rattle & Pointer in a suitable pocket or pouch, ensuring that it does not obstruct or hinder the safe operation of other equipment, interfere with other persons or cause damage to the underwater environment.
4. When use of your Beaver Scuba Rattle and Pointer is required, carefully remove from the pocket or pouch and attach to your wrist by placing your hand through the wrist lanyard supplied and secure in place by pressing the spring on the Side Release Buckle. Slide the Side Release Buckle up the cord until it is positioned securely and release the spring.
5. Hold securely in your hand and shake to attract the attention of other divers or point to features, wildlife or situations while under water.
6. After use, remove from your wrist by pressing the spring and sliding the Side Release Buckle away from your wrist, release when enough distance is attained. Carefully return to your desired stored position.
7. After diving, rinse with fresh water and occasionally grease metal parts with silicone Grease such as Beaver Aquagel and store in a dry and warm location.

CAUTION

All watersports are potentially hazardous. Before using any watersports equipment you should be properly trained and certified in its use by a recognised club or organisation.

PLEASE RETAIN WITH RECEIPT FOR GUARANTEE PURPOSES

email: sales@beaversports.co.uk

web: www.beaversports.co.uk